

Technical Data Sheet

Pressure / Temperature / Humidity / Air Velocity / Airflow / Sound level

KISTOCK DATALOGGER KT 320 / KTT 320

Temperature / Humidity / Voltage/ Current / Impulsion

KEY POINTS

- · Software for configuration and data visualisation freely downloadable
- Software for configuration and data processing available in option
- Safety lock wall mount with inviolability system
- Storage capacity of 2 000 000 points
- Fast data downloading: 18 000 points/s
- Up to 5 recordable parameters simultaneously
- 2 configurable setpoint alarms for each channel
- 2 lines LCD screen
- Bluetooth® communication for smartphones and tablets (Android and IOS)
- Magnetic mounting





REFERENCES

Device reference	Display	Internal sensor		External sensor			Number of
		Number	Туре	Number	Туре	Parameters	record points
KT 320	Yes	1	Temperature	2	Input for SMART PLUG* probes	Temperature, humidity, current, voltage, impulsion	2 000 000
KTT 320		-		4	Input for thermocouple probes	Temperature	2 000 000



For a fast measurement of temperature and humidity variations, it is better to use a remote probe (KITHA, KITHP-130 or KITHI-150 probe, see page 4).

HOUSING

Dimensions

110.2 x 79 x 35.4 mm

Weight

KT 320: 206 g KTT 320: 200 g

Display

2 lines LCD screen

Dimensions of screen: 49.5 x 45 mm 2 indication LEDs (red and green)

Control

1 OK key 1 Selection key

Material

Compatible with food industry environment ABS housing

Battery power supply

2 lithium double AA 3.6 V batteries

Environmental conditions of use

Air and neutral gases

PC communication

1 micro-USB input

Protection

IP 65: KT 320

IP 54: KTT 320**

Hygrometry: in non condensing conditions

Maximum altitude: 2000 m

^{*} Input which allows to plug different compatible SMART PLUG probes: see optional probes and cables page 5.

^{**} With all thermocouple probes connected.

	KT 320	KTT 320			
Parameter	Temperature, humidity, current, voltage, impulsion	Temperature			
Units displayed¹	°C, °F, °Ctd, °Ftd, %RH, mV, V, mA, A <u>Programmed units:</u> please see the class 320 KISTOCK user manual. <u>Free units:</u> for the free units creation, please see the KILOG software user manual.	°C, °F			
Resolution	0.1°C, 0.1°F, 0.1 %RH, 1 mV, 0.001 V, 0.001 mA, 0.1 A	0.1°C, 0.1°F			
External input	Micro-USB female connector				
Input for probe	2 SMART PLUG² inputs	4 inputs for thermocouple probes (K, J, T, N, S)			
Internal sensor	Temperature	-			
Type of sensor	NTC	Thermocouple			
Measuring range	Measuring range of the internal sensor ³ : From -40 to +70°C	K: from -200 to +1300°C J: from -100 to +750°C T: from -200 to +400°C N: from -200 to +1300°C S: from 0 to 1760°C			
Accuracies ⁴	±0.4°C from -20 to 70°C ±0.8°C below -20°C	K, J, T, N: ±0.4°C from 0 to 1300°C ±(0.3% of the reading +0.4°C) below 0°C S: ±0.6°C			
Setpoints alarms	2 setpoint alarms on each channel				
Frequency of measurement	From 1 second to 24 hours				
Operating temperature*	From -40 to +70°C	From -20 to 70°C			
Storage temperature	From -40 to +85°C				
Battery life	7 years⁵				
European directives	2011/65/EU RoHS II ; 2012/19/EU WEEE ; 2014/30/EU EMC ; 2014/35/EU				

¹ Some units are available only with optional probes.

CONNECTIONS

KT 320: 2 mini-DIN connections

KTT 320: 4 mini-thermocouples connections



PC connection



 $^{^{\}rm 2}$ Input which allows to plug different compatible probes: see optional probes and cables page 3.

³ Other measuring ranges are available according to the connected probe: see optional probes and cables page 3.

⁴ All accuracies indicated in this document were stated in laboratory conditions and can be guaranteed for measurement carried out in the same conditions, or carried out with calibration compensation.

⁵ On the basis of 1 measurement each 15 minutes at 25°C.,

^{*}The screen can be hard to read, and its display speed often slows down at temperatures lower than 0°C. This has no effect on the accuracy of measurements.

RECORDER FUNCTIONS

5 recording modes

KISTOCK can record in 5 different ways:

- "Immediate" mode records values according to a predefined interval.
- "Minimum", "Maximum" and "Average" record automatically the calculation of minimum, maximum or average of measured values during an interval of recording.
- "Monitoring" mode allows to get an accurate history report during error events to help troubleshooting, without stopping the measurement logging. To proceed this way, you just have to define:
- a record interval to be used whilst the readings are beyond the setpoints.
- a record interval for the values measured during each reading beyond the setpoints. Furthermore, you can also let your KISTOCK record non-stop ("loop" recording option).

4 types of dataset start

Once your recording mode has been set, you can launch your dataset :

- With a delayed start (with predefined date and time)
- · With the software
- With push-button
- With "Online" option. In this case, your datasets are directly sent, saved and displayed on your PC in real time.


6 types of dataset stop

You can stop your dataset :

- According to a date and time (if it was started the same way)
- · According to a period
- According to a predefined number of recording points
- Once the storage capacity is full
- With "Stop" option of the software
- By holding "OK" key during 5 seconds, if this function has been previously activated by the software

KT 320 KT 320 KTT 320

DISPLAY



END DATASET is finished.

REC Indicates that one value is being recorded.

It flashes: the DATASET did not start already.

FULL Flashing slowly: DATASET is between 80 and 90 % of the storage capacity. Flashing quickly: DATASET is between 90 and 100 % of the storage capacity. Constant: storage capacity full.

BAT Constant: indicates that the batteries have to be replaced.

ACT Screen actualisation of measured values.

The displayed values are the maximum/minimum values recorded for the channels displayed.

Indicates the alarm action type: rising or falling action.

Temperature in °Celsius.

Temperature in °Fahrenheit .

Relative humidity

Indicates the channel number which is measuring.

OPTIONAL PROBES AND CABLES¹



All the probes for the **KT 320** KISTOCK have the **SMART PLUG** technology.

An automatic recognition and the adjustment parameters storage make them 100 % interchangeable.

Reference	Description	Measuring range	
External or ambient therm	no-hygrometric probes		
KITHA	Interchangeable hygrometry and ambient temperature probe	Hygrometry: from 0 to 100%HR Temperature: from -20 to +70°C	
KITHP-130	Remote interchangeable hygrometry and temperature probe		
KITHI-150	Remote interchangeable hygrometry and temperature probe	Hygrometry: from 0 to 100 % HR Temperature: from -40 to +180°C	
General use or insertion F	Pt 100 temperature probes		
KIRGA-50 / KIRGA-150	IP65 immersion probe (50 or 150 mm)	From -40 to +120°C	
KIRAM-150	Ambient probe 150 mm		
KIRPA-150	Penetration probe IP65	From F0 to 1950°C	
KIPI3-150-E	IP68 penetration probe with handle		
KITI3-100-E	IP68 penetration probe with T-handle	From -50 to +250°C	
KITBI3-100-E	IP68 penetration probe with corkscrew handle		
KIRV-320	Velcro probe	From -20 to +90°C	
KICA-320	Smart adapter for Pt100 probe	From -200 to +600°C according to the probe	
Input current, voltage and	impulsion cables		
KICT	Voltage input cable	0-5 V or 0-10 V	
KICC	Current input cable	0-20 mA or 4-20 mA	
KICI	Pulse input cable	Maximal voltage: 5 V Type of input: TTL frequency counting Maximal frequency: 10 kHz Maximum number of recordable points: 20 000 points	
Clamp-on ammeters			
KIPID-50	Ammeter clamp from 0 to 50 A, frequency range from 40 to 5000 Hz	From 0 to 50 A _{AC}	
KIPID-100	Ammeter clamp from 0 to 100 A, frequency range from 40 to 5000 Hz	From 1 to 100 A _{AC}	
KIPID-200	Ammeter clamp from 0 to 200 A, frequency range from 40 to 5000 Hz	From 1 to 200 A _{AC}	
KIPID-600	Ammeter clamp from 0 to 600 A, frequency range from 40 to 5000 Hz	From 1 to 600 A _{AC}	
Thermocouple probes			

All the thermocouple temperature probes for the **KTT 320** KISTOCK have a class 1 sensitive element as per IEC 584-1, 2 and 3 standards. For more details about the available thermocouple probes, please see the "Thermocouple probes" datasheet.

¹ For more details, please see the "Measuring probes for KT 320 KISTOCK" and "Thermocouple probes" datasheets

SOFTWARE



KILOG LITE: free software to download on the KIMO website (kimo.fr).
 Allows the data download (graphics and points statement) and the datalogger configuration.



- Configuration and data processing software KILOG software allows to configure, save and process your data in a very simple way.
- Software only: Ref. KILOG-3-N
- Complete set: software + 1 USB cable, Ref. KIC-3-N

SAFETY LOCK WALL MOUNT WITH PADLOCK



The system allows to secure your KISTOCK datalogger on sensitive sites.



- > Mount the safety lock support on the required place.
- 1. Present the KISTOCK datalogger on the support starting with the inferior part
- 2. Clip the KISTOCK on the support by falling back the superior part
- 3. Insert the padlock to ensure the safety lock function




The padlock can be replaced by a fail-safe sealed




The datalogger can be placed on the screw-mount without the safety lock function

> To remove the datalogger from the support, proceed on reverse order.






The KISTOCK class 320 have a magnetic mounting, so you can fix it easily.



DIMENSIONS OF THE WALL MOUNT (in mm)



CALIBRATION

A calibration certificate is available as option in paper format. We recommend to carry out a yearly checking.

MAINTENANCE

Please avoid any aggressive solvent.

Please protect the device and probes from any cleaning produce containing formalin, that may be used for cleaning rooms and ducts.

GUARANTEE PERIOD

KISTOCK dataloggers have 1-year guarantee for any manufacturing defect (return to our After-sales service required).

PRECAUTIONS FOR USE

Please always use the device in accordance with its intended use and within parameters described in the technical features in order not to compromise the protection ensured by the device.

REPLACE THE BATTERIES



With 7 years* of battery life, the KISTOCK devices guarantee long-term measurements.

To replace the batteries:

- Unscrew the screw on the back side of the KISTOCK, on the battery hatch, with a cross-headed screwdriver.
- Remove the hatch and the old batteries.
- Insert the new batteries and respect the polarity.
- Replace the battery hatch and screw it.
- * On the basis of 1 measurement each 15 minutes at 25°C.



BE CAREFUL! Material damages can happen, so please apply the precautionary measures indicated.



Once returned to KIMO, required waste collection will be assured in the respect of the environment in accordance to guidelines relating to WEEE.

大華高科股份有限公司

www.taiwah.com.tw info@taiwah.com.tw

台北 TEL: (02) 2592 - 5119 Fax: (02) 2592-3577 台中 TEL: (04) 2707 - 2269 Fax: (04) 2707-1799 台南 TEL: (06) 243 - 2338 Fax: (06) 243 - 2339 KIMO® 為 KIMO 儀器公司的注冊商標。

資料中任何商標和圖片為本公司版權所有。未經本公司書面許可 不得以任何形式複製,轉印,發行或儲存資料中所包含的訊息。 本資料如有變更,恕不另行通知。